

# Selexsorb<sup>®</sup> CD/CDX/CDL

## Adsorbents for the removal of polar compounds

**The present guideline provides information on how to bring the indicated adsorbents into contact with liquids and gases.**

### Background

Selexsorb CD/CDX/CDL are often used for the treatment of hydrocarbon streams in liquid or vapor phase operation. These hydrocarbon streams can contain smaller or larger amounts of olefins or even multiple unsaturated components (like acetylenes). All these unsaturated components can either react with themselves or with each other if heated to a sufficiently high temperature.

High temperatures can occur if beds are not properly cooled down after regeneration or when brought first into contact with the respective hydrocarbon streams. Certain hydrocarbons can indeed exhibit high energies of adsorption, which, if not properly addressed, can lead to local temperature increases and as consequence reactions of unsaturated components.

Selexsorb CD/CDX/CDL have a very long history of being started up with no or only minor temperature increases observed. Selexsorb materials have been specifically developed for allowing start-up with olefins present, avoiding the typical pre-loading procedure as e.g. used for certain mol sieves like 13X.

In the following, measures are indicated to minimize local temperature increases.

Before any of the fillings described in the following is carried out, it is imperative to check whether at all enough volume of the gas or liquid is available to fill the vessel within the indicated time frame. The required volume needed can be approximated with

the volume of the empty vessel minus 1/3 of the volume filled with adsorbent.

### Contacting with Gases

The following indications are based on the example of a stream consisting mostly of ethylene.

Typically, the vessel is kept under an inert gas (nitrogen, fuel gas free of olefins or other). The adsorbent must be properly cooled down (a regeneration is typically done before bringing the adsorbent in contact with any stream to be treated).

- If nitrogen is available with sufficiently high pressure, the vessel can be pressurized to operating pressure with nitrogen alone and can then be lined out with the rest of the system. A continuous flow is then established through the vessel.
- If only lower pressure nitrogen is available (e.g. 8 bar(g)/120 psig(g)) the vessel can first be pressurized with nitrogen and then with feed itself up to the required operating pressure. However, this pressurization step with feed should be done as fast as possible (within a few minutes). Once the vessel is at operating pressure, the system is directly lined out and a continuous flow is immediately established through the vessel.
- Alternatively the vessel can also be pressurized with feed alone (again within a few minutes only) and must then be directly lined out with the rest of the system and a continuous flow through the vessel must be established.

In case any larger temperature increases are observed during pressurization, the procedure must be stopped and the vessel must be directly depressurized. Depressurization is preferably done co-currently with the direction the vessel was being pressurized with.

### Contact with Liquids

The following indications are based on the example of a stream consisting mostly of propylene (as example of an LPG type stream). Typically the vessel is kept under an inert gas (nitrogen, fuel gas free of olefins or other). The adsorbent must be properly cooled down (a regeneration is typically done before bringing the adsorbent in contact with any stream to be treated). The additional difficulty with LPG type streams is that these can flash to very low temperatures (below the allowed lower temperature limits of the steel used for vessel and piping) if these liquids are flashed against too low a pressure.

- If nitrogen is available with sufficiently high pressure, the vessel can be pressurized to operating pressure with nitrogen alone. Once the vessel is at operating pressure, it will be filled from the bottom with the liquid feed while the nitrogen is vented. Once the vessel is completely filled, the vessel will be lined out with the rest of the system and a continuous flow will be established without any delay. The filling with liquid must be done within 2–3 hours maximum
- If only lower pressure nitrogen is available (e.g. 8 bar (g) /120 psig (g)) the vessel can first be pressurized with nitrogen and then with vaporized feed itself to the required operating pressure. However this pressurization step with the vapor should be done as fast as possible (within a few minutes). Once the vessel is at operating pressure, it will be filled from the bottom with the liquid feed while the gas phase (consisting of nitrogen and vaporized propylene) is vented. Once the vessel is completely filled, the vessel will be lined out with the rest of the system and a continuous flow will be established without any delay. The filling with liquid must be done within 2–3 hours maximum. Vapor for this type of

operation might e.g. be coming from a propylene splitter. In this case it is preferable to use the propane rich vapor coming from the bottom of the splitter.

- A pressurization of the vessel with vaporized feed alone is not allowed. If pressurization with nitrogen is not possible, the adsorbent in the vessel must be pre-loaded. The pre-loading step often consists of sending the regeneration gas stream loaded with 1–2 vol % of vaporized feed through the vessel until the adsorbent is completely loaded with feed. This is of course only done after having properly cooled down the bed. Alternatively also nitrogen can be used as carrier gas. After the pre-loading has been completed, the vessel can be pressurized with vaporized feed alone to operating pressure.

In case any larger temperature increases are observed during pressurization, the procedure must be directly stopped and the system immediately depressurized preferably co-current to the direction of pressurization.

If during filling with liquid any larger temperature increases are observed, the procedure must be directly stopped, the vessel must be depressurized and flushed immediately after with an inert gas like nitrogen. Again, the depressurization and nitrogen purge steps are preferably done co-currently to the direction of pressurization.

If in doubt about the right procedure to be applied, please feel free to contact BASF.

### Note

It must also be noted that all indications provided apply only to one vessel loaded with the respective Selexsorb adsorbent. Any procedure set up by the customer and trying to fill e.g. multiple vessel systems lined up in series or in parallel is the sole responsibility of the respective customer. Also, proper instrumentation must be in place to monitor the respective steps indicated above. Proper instrumentation are typically temperature measurements, pressure measurements and the case being the analysis of hydrocarbons in inert streams.

## About Us

BASF's Catalysts division is the world's leading supplier of environmental and process catalysts. The group offers exceptional expertise in the development of technologies that protect the air we breathe, produce the fuels that power our world and ensure efficient production of a wide variety of chemicals, plastics and other products, including advanced battery materials. By leveraging our industry-leading R&D platforms, passion for innovation and deep knowledge of precious and base metals, BASF's Catalysts division develops unique, proprietary solutions that drive customer success.

**BASF - We create chemistry**

### Americas

BASF Corporation  
25 Middlesex/Essex Turnpike  
Iselin, New Jersey, 08830, USA  
Tel : +1-732-205-5000  
Fax: +1-732-205-7725  
Email: [catalysts-america@basf.com](mailto:catalysts-america@basf.com)

### Asia Pacific

BASF (China) Company Limited  
300 Jiang Xin Sha Road,  
Pudong, Shanghai 200137  
P.R. China  
Tel: +86-21-2039 2549  
Fax: +86-21-2039 4800-2549  
Email: [catalysts-asia@basf.com](mailto:catalysts-asia@basf.com)

### Europe, Middle East, Africa

BASF De Meern BV Catalysts  
The Netherlands  
Tel: +31-30-666 9437  
Email: [catalysts-europe@basf.com](mailto:catalysts-europe@basf.com)

*Selexorb* is a trademark of BASF.

Although all statements and information in this publication are believed to be accurate and reliable, they are presented gratis and for guidance only, and risks and liability for results obtained by use of the products or application of the suggestions described are assumed by the user. NO WARRANTIES OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, ARE MADE REGARDING PRODUCTS DESCRIBED OR DESIGNS, DATA OR INFORMATION SET FORTH. Statements or suggestions concerning possible use of the products are made without representation or warranty that any such use is free of patent infringement and are not recommendations to infringe any patent. The user should not assume that toxicity data and safety measures are indicated or that other measures may not be required. © 2015 BASF

BASF-9804 Rev. 12/18